


1-A Location of controls


DIALING MODE Selector (1-B)




RINGER Selector (1-B)

1-B Settings

- 1 Connect the telephone line cord(①).
- 2 Connect the handset cord(②), then confirm the dial tone.




- 3 Set the DIALING MODE selector to TONE



4 Set the RINGER selector to HIGH, LOW .

(EX. "LOW" is selected.)



When set to OFF, the unit will not ring.

2-A Making Calls

- 1 Lift the handset.
- 2 Dial a phone number.

If you misdial, hang up and start again from step 1.

- 3 When finished talking, hang up.

To redial the last number dialed

Lift the handset. ➡ Press **REDIAL**.

2-B Answering Calls

- 1 When the unit rings, lift the handset.
- 2 When finished talking, hang up.

2-C Other Functions

- 1 Press **R/FLASH** to auto-hang up.
- 2 Press **MUTE** to mute a call.
- 3 Press **PAUSE** to add in a pause.



